



HIMax[®]

Digital Output Module
Manual

SAFETY
NONSTOP



X-DO 24 01

All HIMA products mentioned in this manual are protected by the HIMA trade-mark. Unless noted otherwise, this also applies to other manufacturers and their respective products referred to herein.

All of the instructions and technical specifications in this manual have been written with great care and effective quality assurance measures have been implemented to ensure their validity. For questions, please contact HIMA directly. HIMA appreciates any suggestion on which information should be included in the manual.

Equipment subject to change without notice. HIMA also reserves the right to modify the written material without prior notice.

For further information, refer to the HIMA DVD and our website at <http://www.hima.de> and <http://www.hima.com>.

© Copyright 2012, HIMA Paul Hildebrandt GmbH + Co KG

All rights reserved

Contact

HIMA Address

HIMA Paul Hildebrandt GmbH + Co KG

P.O. Box 1261

68777 Brühl, Germany

Phone: +49 6202 709-0

Fax: +49 6202 709-107

E-mail: info@hima.com

Revision index	Revisions	Type of Change	
		technical	editorial
4.00	New edition for SILworX V4	X	X
5.00	Updated edition for SILworX V5		X

Table of Contents

1	Introduction	5
1.1	Structure and Use of the Manual	5
1.2	Target Audience	5
1.3	Formatting Conventions	6
1.3.1	Safety Notes	6
1.3.2	Operating Tips	7
2	Safety	8
2.1	Intended Use	8
2.1.1	Environmental Requirements	8
2.1.2	ESD Protective Measures	8
2.2	Residual Risk	9
2.3	Safety Precautions	9
2.4	Emergency Information	9
3	Product Description	10
3.1	Safety Function	10
3.1.1	Reaction in the Event of a Fault	10
3.2	Scope of Delivery	10
3.3	Type Label	11
3.4	Structure	12
3.4.1	Block Diagram	13
3.4.2	Indicators	14
3.4.3	Module Status Indicators	15
3.4.4	System Bus Indicators	16
3.4.5	I/O Indicators	16
3.5	Product Data	17
3.6	Connector Boards	19
3.6.1	Mechanical Coding of Connector Boards	19
3.6.2	Coding of X-CB 009 Connector Boards	20
3.6.3	Connector Boards with Screw Terminals	21
3.6.4	Terminal Assignment for Connector Boards with Screw Terminals	22
3.6.5	Connector Boards with Cable Plug	24
3.6.6	Pin Assignment for Connector Boards with Cable Plug	25
3.7	System Cable X-CA 010	26
3.7.1	Cable Plug Coding	27

4	Start-up	28
4.1	Mounting	28
4.1.1	Wiring Outputs not in Use	28
4.2	Mounting and Removing the Module	29
4.2.1	Mounting a Connector Board	29
4.2.2	Mounting and Removing the Module	31
4.3	Line monitoring (SC/OC)	33
4.3.1	Recommended Values for Line Monitoring	33
4.4	Configuring the Module in SILworX	34
4.4.1	Tab: Module	35
4.4.2	Tab: I/O Submodule DO24_01	36
4.4.3	Tab: I/O Submodule DO24_01: Channels	37
4.4.4	Submodule State [DWORD]	38
4.4.5	Diagnostic Status [DWORD]	39
4.5	Connection Variants	40
4.5.1	Wiring Actuators	40
4.5.2	Redundant Wiring of Actuators via Two Modules	41
4.5.3	Wiring Inductive Loads	42
4.5.4	Wiring Actuators via Field Termination Assembly	42
5	Operation	43
5.1	Handling	43
5.2	Diagnosis	43
6	Maintenance	44
6.1	Maintenance Measures	44
6.1.1	Loading the Operating System	44
6.1.2	Proof Test	44
7	Decommissioning	45
8	Transport	46
9	Disposal	47
	Appendix	49
	Glossary	49
	Index of Figures	50
	Index of Tables	51
	Index	52

1 Introduction

The present manual describes the technical characteristics of the module and its use. It provides information on how to install, start up and configure the module in SILworX.

1.1 Structure and Use of the Manual

The content of this manual is part of the hardware description of the HIMax programmable electronic system.

This manual is organized in the following main chapters:

- Introduction
- Safety
- Product Description
- Start-up
- Operation
- Maintenance
- Decommissioning
- Transport
- Disposal

Additionally, the following documents must be taken into account:

Name	Content	Document no.
HIMax System Manual	Hardware description of the HIMax system	HI 801 001 E
HIMax Safety Manual	Safety functions of the HIMax systems	HI 801 003 E
HIMax Communication Manual	Description of communication and protocols	HI 801 101 E
SILworX Online Help (OLH)	Instructions on how to use SILworX	-
First Steps	Introduction to SILworX	HI 801 103 E

Table 1: Additional Valid Manuals

The latest manuals can be downloaded from the HIMA website at www.hima.com. The revision index on the footer can be used to compare the current version of existing manuals with the Internet edition.

1.2 Target Audience

This document addresses system planners, configuration engineers, programmers of automation devices and personnel authorized to implement, operate and maintain the devices and systems. Specialized knowledge of safety-related automation systems is required.

1.3 Formatting Conventions

To ensure improved readability and comprehensibility, the following fonts are used in this document:

Bold:	To highlight important parts Names of buttons, menu functions and tabs that can be clicked and used in SILworX.
<i>Italics:</i>	System parameter and variables
Courier	Literal user inputs
RUN	Operating state are designated by capitals
Chapter 1.2.3	Cross references are hyperlinks even though they are not particularly marked. When the cursor hovers over a hyperlink, it changes its shape. Click the hyperlink to jump to the corresponding position.

Safety notes and operating tips are particularly marked.

1.3.1 Safety Notes

The safety notes are represented as described below.

These notes must absolutely be observed to reduce the risk to a minimum. The content is structured as follows:

- Signal word: danger, warning, caution, notice
- Type and source of danger
- Consequences arising from the danger
- Danger prevention

SIGNAL WORD



Type and source of danger!
Consequences arising from the danger
Danger prevention

The signal words have the following meanings:

- Danger indicates hazardous situation which, if not avoided, will result in death or serious injury.
- Warning indicates hazardous situation which, if not avoided, could result in death or serious injury.
- Caution indicates hazardous situation which, if not avoided, could result in minor or modest injury.
- Notice indicates a hazardous situation which, if not avoided, could result in property damage.

NOTICE



Type and source of damage!
Damage prevention

1.3.2 Operating Tips

Additional information is structured as presented in the following example:

i

The text corresponding to the additional information is located here.

Useful tips and tricks appear as follows:

TIP

The tip text is located here.

2 Safety

All safety information, notes and instructions specified in this manual must be strictly observed. The product may only be used if all guidelines and safety instructions are adhered to.

This product is operated in accordance with SELV or PELV. No imminent danger results from the module itself. The use in Ex-Zone is permitted if additional measures are taken.

2.1 Intended Use

HIMax components are designed for assembling safety-related controller systems.

When using the components in the HIMax system, comply with the following general requirements

2.1.1 Environmental Requirements

Requirement type	Range of values
Protection class	Protection class III in accordance with IEC/EN 61131-2
Ambient temperature	0...+60 °C
Storage temperature	-40...+85 °C
Pollution	Pollution degree II in accordance with IEC/EN 61131-2
Altitude	< 2000 m
Housing	Standard: IP20
Supply voltage	24 VDC

Table 2: Environmental Requirements

Exposing the HIMax system to environmental conditions other than those specified in this manual can cause the HIMax system to malfunction.

2.1.2 ESD Protective Measures

Only personnel with knowledge of ESD protective measures may modify or extend the system or replace modules.

NOTE



Device damage due to electrostatic discharge!

- When performing the work, make sure that the working area is free of static and wear an ESD wrist strap.
- If not used, ensure that the device is protected from electrostatic discharge, e.g., by storing it in its packaging.

2.2 Residual Risk

No imminent danger results from a HIMax module itself.

Residual risk may result from:

- Faults in the engineering
- Faults in the user program
- Faults in the wiring

2.3 Safety Precautions

Observe all local safety requirements and use the protective equipment required on site.

2.4 Emergency Information

A HIMax controller is a part of the safety equipment of a system. If the controller fails, the system adopts the safe state.

In case of emergency, no action that may prevent the HIMax systems from operating safely is permitted.

3 Product Description

The X-DO 24 01 digital output module is intended for use in the programmable electronic system (PES) HIMax.

The module can be inserted into any of the base plate slots with the exception of the slots reserved for system bus modules. For more information, refer to the System Manual (HI 801 001 E).

The module is equipped with 24 digital outputs that can be loaded with a nominal current of up to 0.5 A per channel. The supply voltage minus internal voltage drop is present on the outputs.

The outputs are suitable for connecting ohmic, inductive and capacitive loads and lamps.

The module has been certified by the TÜV for safety-related applications up to SIL 3 (IEC 61508, IEC 61511 and IEC 62061) as well as Cat. 4 and PL e (EN ISO 13849-1).

Refer to the HIMax Safety Manual (HI 801 003 E) for more information on the standards used to test and certify the module and the HIMax system.

3.1 Safety Function

The module ensures its safety function using three safety switches connected in series for each channel. This ensures that each output is two-fault-tolerant with respect to the safety switch. Each safety switch of a channel can be individually switched off either via the system bus (I/O bus) or via the second independent shutdown function (watchdog).

The safe output state is the de-energized state. Redundant processor systems monitor the values expected for the outputs. Outputs that do not correspond to the expected values are reset. One of the two read-back branches that were monitored for their expected values can be tested.

The safety function is performed in accordance with SIL 3.

3.1.1 Reaction in the Event of a Fault

If a fault is detected, the module adopts the safe state and all the outputs are de-energized in accordance with the 'de-energize to trip principle'. If a channel fault occurs, only the corresponding output is switched off; if a module fault occurs, all module outputs are switched off.

If the system bus fails, the outputs are de-energized.

The module activates the *Error* LED on the front plate.

3.2 Scope of Delivery

The module must be installed on a suitable connector board to be able to operate. If a Field Termination Assembly (FTA) is used, a system cable is required to connect the connector board to the FTA. Connector boards, system cables and FTAs are not included within the scope of delivery.

The connector boards are described in Chapter 3.6, the system cables are described in Chapter 3.7. The FTAs are described in own manuals.

3.3 Type Label

The type label specifies the following important details:

- Product name
- Mark of conformity
- Bar code (2D or 1D code)
- Part number (Part-No.)
- Hardware revision index (HW Rev.)
- Software revision index (SW Rev.)
- Operating voltage (Power)
- Ex specifications (if applicable)
- Production year (Prod-Year:)



Figure 1: Sample Type Label

3.4 Structure

The module is equipped with 24 digital outputs. The outputs are not electrically isolated from one another and from the voltage supply.

The module is equipped with line monitoring (SC/OC). If the open-circuit monitoring is configured in SILworX, see Chapter 4.3, the channels are automatically checked for open-circuits (OC) and short-circuits (SC). The switching thresholds for line monitoring are predefined and cannot be modified.

The outputs are protected against high currents. If a short-circuit occurs, the current at each output is limited to 2 A.

If a current higher than 0.75 A flows through an output for 50 ms, the affected output is switched off for 5 s. If the overcurrent is still present after the outputs is automatically re-switched on, the output is switched off again for 5 s. This process is repeated as long as the overcurrent is present. If the cyclic switch-on after overcurrent must be prevented, the user program must be configured accordingly.

The safety-related 1oo2 processor system for the I/O module controls and monitors the I/O level. The data and states of the I/O module are made available to the processor modules via the redundant system bus. The system bus has a redundant structure for reasons of availability. Redundancy is only ensured if both system bus modules are inserted in the base plates and configured in SILworX.

The module is equipped with LEDs to indicate the status of the digital outputs, see Chapter 3.4.2.

3.4.1 Block Diagram

The following block diagram illustrates the structure of the module.




Figure 2: Block Diagram

3.4.2 Indicators

The following figure shows the LED indicators for the module.




Figure 3: Indicators

The LEDs indicate the operating state of the output module.

The LEDs on the module are divided into three groups:

- Module status indicators (Run, Error, Stop, Init)
- System bus indicators (A, B)
- I/O indicators (DO 1...24, Field)

When the supply voltage is switched on, a LED test is performed and all LEDs briefly flash simultaneously.

Definition of Blinking Frequencies

The following table defines the blinking frequencies of the LEDs:

Name	Blinking Frequencies
Blinking1	Long (approx. 600 ms) on, long (approx. 600 ms) off
Blinking2	Short (approx. 200 ms) on, short (approx. 200 ms) off, short (approx. 200 ms) on, long (approx. 600 ms) off
Blinking-x	Ethernet communication: Flashing in sync with data transfer

Table 3: Blinking Frequencies of LEDs

3.4.3 Module Status Indicators

These LEDs are located on the front plate, on the upper part of the module.

LED	Color	Status	Description
Run	Green	On	Module in RUN, normal operation
		Blinking1	Module state: STOP/OS_DOWNLOAD or OPERATE (only with processor modules)
		Off	Module not in RUN, observe the other status LEDs
Error	Red	On/Blinking1	Internal module faults detected by self-tests, e.g., hardware, software or voltage supply. Fault while loading the operating system
		Off	Normal operation
Stop	Yellow	On	Module state: STOP / VALID CONFIGURATION
		Blinking1	Module state: STOP / INVALID CONFIGURATION or STOP / OS_DOWNLOAD
		Off	Module not in STOP, observe the other status LEDs
Init	Yellow	On	Module state: INIT, observe the other status LEDs
		Blinking1	Module state: LOCKED, observe to the other status LEDs
		Off	Module state: neither INIT nor LOCKED, observe the other status LEDs

Table 4: Module Status Indicators

3.4.4 System Bus Indicators

The system bus LEDs are labeled *Sys Bus*.

LED	Color	Status	Description
A	Green	On	Physical and logical connection to the system bus module in slot 1.
		Blinking1	No physical connection to the system bus module in slot 1.
	Yellow	Blinking1	The physical connection to the system bus module in slot 1 has been established. No connection to a (redundant) processor module running in system operation.
B	Green	On	Physical and logical connection to the system bus module in slot 2.
		Blinking1	No physical connection to the system bus module in slot 2.
	Yellow	Blinking1	The physical connection to the system bus module in slot 2 has been established. No connection to a (redundant) processor module running in system operation.
A+B	Off	Off	Neither physical nor logical connection to the system bus modules in slot 1 and slot 2.

Table 5: System Bus Indicators

3.4.5 I/O Indicators

The LEDs of the I/O indicator are labeled *Channel*.

LED	Color	Status	Description
Channel 1...24	Yellow	On	The related channel is active (energized).
		Blinking2	The related channel is faulty.
		Off	The related channel is inactive (de-energized).
Field	Red	Blinking2	Field fault on at least one channel, e.g., open-circuit, short-circuit, over-current, etc.
		Off	No field fault displayed!

Table 6: I/O Indicators

3.5 Product Data

General	
Supply voltage	24 VDC, -15...+20 %, $r_p \leq 5\%$, PELV, SELV
Current input	min. 0.5 A (idle)
Continuous load	max. 12 A at 24 VDC
Electrical isolation	No
Operating temperature	0...+60 °C
Storage temperature	-40...+85 °C
Humidity	max. 95 % relative humidity, non-condensing
Type of protection	IP20
Dimensions (H x W x D)	310 x 29.2 x 230 mm
Weight	approx. 1.0 kg

Table 7: Product Data




Figure 4: Views

Digital Outputs	
Number of outputs (number of channels)	24, non-electrically isolated
Output voltage	$\geq L+$ minus internal voltage drop
Voltage drop (with high level)	0.8 V at 0.75 A output current
Nominal rated current (with high level)	0.5 A, range 0.01...0.6 A
Total current permitted for the module	12 A
Leakage current (with low level)	$< 500 \mu\text{A}$
Overcurrent interruption	$I > 0.75 \text{ A}$
Current limiting in the event of short-circuit	2 A
Behavior in the Event of Overcurrent and Short-Circuits	The affected output is switched off and cyclically switched on again, see Chapter 3.4.
Ohmic load	To nom. rated current 0.5 A
Inductive load	max. 50 H
Lamp load (24 V lamps)	max. 4 W
Capacitive load	max. 100 μF
Line monitoring	
OC Limit	$\leq 5 \text{ mA}$
SC Limit	0.75 A (range 0.75...0.8 A)
Overvoltage protection of the outputs, transient	33 V (max. 43 V)
Switching time of the channels (with ohmic load)	$\leq 100 \mu\text{s}$
Test impulse (with ohmic load)	typ. 200 μs

Table 8: Specifications for the Digital Outputs

3.6 Connector Boards

A connector board connects the module to the field zone. Module and connector board form together a functional unit. Insert the connector board into the appropriate slot prior to mounting the module.

The following connector boards are available for the module:

Connector board	Description
X-CB 009 01	Connector board with screw terminals
X-CB 009 02	Redundant connector board with screw terminals
X-CB 009 03	Connector board with cable plug
X-CB 009 04	Redundant connector board with cable plug


Table 9: Available Connector Boards

3.6.1 Mechanical Coding of Connector Boards

I/O modules and connector boards are mechanically coded starting from hardware revision AS10 to prevent them from being equipped with improper I/O modules. Coding avoids incorrect installation of improper I/O modules thus preventing negative effects on redundant modules and field zone. A part from that, improper equipment has no effect on the HIMax system since only I/O modules that are correctly configured in SILworX enter the RUN state.

I/O modules and the corresponding connector boards have a mechanical coding in form of wedges. The coding wedges in the female connector of the connector board match with the male connector recesses of the I/O module plug, see Figure 5.

Coded I/O modules can only be plugged in to the corresponding connector boards.



- 1** Male Connector Recess
- 2** Prepared Male Connector Recess
- 3** Coding Wedge
- 4** Guideway for Coding Wedge

Figure 5: Coding Example

Coded I/O modules can be plugged in to uncoded connector boards. Uncoded I/O modules cannot be plugged in to coded connector boards.

3.6.2 Coding of X-CB 009 Connector Boards

a7	a13	a20	a26	c7	c13	c20	c26
X	X			X	X		

Table 10: Position of Coding Wedges


3.6.3 Connector Boards with Screw Terminals

Mono

Redundant

X-CB 009 01

X-CB 009 02



1 I/O Module Plug

2 Connection to the Field Zone (Screw Terminal Connector Block)

Figure 6: Connector Boards with Screw Terminals

3.6.4 Terminal Assignment for Connector Boards with Screw Terminals

Pin no.	Designation	Signal	Pin no.	Designation	Signal
1	01a	DO1+	1	02a	DO2+
2	01b	DO1-	2	02b	DO2-
3	03a	DO3+	3	04a	DO4+
4	03b	DO3-	4	04b	DO4-
5	05a	DO5+	5	06a	DO6+
6	05b	DO5-	6	06b	DO6-
7	07a	DO7+	7	08a	DO8+
8	07b	DO7-	8	08b	DO8-
Pin no.	Designation	Signal	Pin no.	Designation	Signal
1	09a	DO9+	1	10a	DO10+
2	09b	DO9-	2	10b	DO10-
3	11a	DO11+	3	12a	DO12+
4	11b	DO11-	4	12b	DO12-
5	13a	DO13+	5	14a	DO14+
6	13b	DO13-	6	14b	DO14-
7	15a	DO15+	7	16a	DO16+
8	15b	DO15-	8	16b	DO16-
Pin no.	Designation	Signal	Pin no.	Designation	Signal
1	17a	DO17+	12	18a	DO18+
2	17b	DO17-	2	18b	DO18-
3	19a	DO19+	3	20a	DO20+
4	19b	DO19-	4	20b	DO20-
5	21a	DO21+	5	22a	DO22+
6	21b	DO21-	6	22b	DO22-
7	23a	DO23+	7	24a	DO24+
8	23b	DO23-	8	24b	DO24-
Pin no.	Designation	Signal	Pin no.	Designation	Signal
1	25a		1	26a	
2	25b		2	26b	
3	27a		3	28a	
4	27b		4	28b	
5	29a		5	30a	
6	29b		6	30b	
7	31a		7	32a	
8	31b		8	32b	

Table 11: Terminal Assignment for Connector Boards with Screw Terminals

Cable plugs attached to the connector board pin headers are used to connect to the field zone.

The cable plugs feature the following properties:

Connection to the field zone	
Cable plugs	8 pieces, with 8 poles
Wire cross-section	0.2...1.5 mm ² (single-wire) 0.2...1.5 mm ² (finely stranded) 0.2...1.5 mm ² (with wire end ferrule)
Stripping length	6 mm
Screwdriver	Slotted 0.4 x 2.5 mm
Tightening torque	0.2...0.25 Nm

Table 12: Cable Plug Properties


3.6.5 Connector Boards with Cable Plug

Mono

Redundant

X-CB 009 03

X-CB 009 04



1 I/O Module Plug

2 Connection to the Field Zone (Cable Plug in Row 1)

3 Connection to the Field Zone (Cable Plug in Row 32)

4 Coding for Cable Plugs

Figure 7: Connector Boards with Cable Plug

3.6.6 Pin Assignment for Connector Boards with Cable Plug

HIMA provides ready-made system cables for use with these connector boards, see Chapter 3.7. Cable plug and connector boards are coded.

i

Connector pin assignment!

The following table describes the connector pin assignment of the system cable plug.

Lead marking based on DIN 47100:

Pin Assignment						
Row	c		b		a	
	Signal	Color	Signal	Color	Signal	Color
1	DO32+		DO32-		Reserved	RD **
2	DO31+		DO31-		Reserved	BU **
3	DO30+		DO30-		Reserved	PK **
4	DO29+		DO29-		Reserved	GY **
5	DO28+		DO28-			
6	DO27+		DO27-			
7	DO26+		DO26-			
8	DO25+		DO25-			
9	DO24+	YE *	DO24-	GN *		
10	DO23+	BN *	DO23-	WH *		
11	DO22+	RDBK	DO22-	BUBK		
12	DO21+	PKBK	DO21-	GYBK		
13	DO20+	PKRD	DO20-	GYRD		
14	DO19+	PKBU	DO19-	GYBU		
15	DO18+	YEBK	DO18-	GNBK		
16	DO17+	YERD	DO17-	GNRD		
17	DO16+	YEBU	DO16-	GNBU		
18	DO15+	YEPK	DO15-	PKGN		
19	DO14+	YEGY	DO14-	GYGN		
20	DO13+	BNBK	DO13-	WHBK		
21	DO12+	BNRD	DO12-	WHRD		
22	DO11+	BNBU	DO11-	WHBU		
23	DO10+	PKBN	DO10-	WHPK		
24	DO9+	GYBN	DO9-	WHGY		
25	DO8+	YEBN	DO8-	WHYE		
26	DO7+	BNGN	DO7-	WHGN		
27	DO6+	RDBU	DO6-	GYPK		
28	DO5+	VT	DO5-	BK		
29	DO4+	RD	DO4-	BU		
30	DO3+	PK	DO3-	GY		
31	DO2+	YE	DO2-	GN		
32	DO1+	BN	DO1-	WH		

^{*)} Additional orange ring if one lead marking color is repeated.
^{**)} Lead marking 2 x 2 x 0.14 mm² (system cable: X-CA 010).


Table 13: Pin Assignment for the System Cable Plug

3.7 System Cable X-CA 010

The X-CA 010 system cable is used to wire the X-CB 009 03/04 connector boards to the field termination assemblies. To connect the module to the FTA, the X-CA 006 system cable can also be used, see the X-DO 32 01 Manual.

General	
Cable	LIYY 48 x 0.5 mm ² + 2 x 2 x 0.14 mm ²
Wire	Finely stranded
Average outer diameter (d)	Max. 20 mm for all types of system cables
Minimum bending radius	
Fixed laying	5 x d
Flexible application	10 x d
Combustion behavior	flame resistant and self-extinguishing in accordance with IEC 60332-1-2, -2-2
Length	8...30 m
Color coding	Based on DIN 47100, see Table 13.

Table 14: Cable Data



1 Identical Cable Plugs

Figure 8: X-CA 010 01 n

The system cable is available in the following standard length:

System Cable	Description	Length
X-CA 010 01 8	Coded cable plugs on both sides	8 m
X-CA 010 01 15		15 m
X-CA 010 01 30		30 m

Table 15: Available System Cables

3.7.1 Cable Plug Coding

The cable plugs are equipped with three coding pins. Cable plugs only match connector boards and FTAs with the corresponding coding, see Figure 7.

4 Start-up

This chapter describes how to install, configure and connect the module. For more information, refer to HIMax System Manual (HI 801 001 E).

i

The safety-related application (SIL 3 in accordance with IEC 61508) of the outputs and the actuators connected must comply with the safety requirements. For more information, refer to the HIMax Safety Manual.

4.1 Mounting

Observe the following points when mounting the module:

- Only operate the module with the appropriate fan components. For more information, see the System Manual (HI 801 001 E).
- Only operate the module with the suitable connector board. For more information, see Chapter 3.6.
- Connection to the field zone with twisted pair wire.
- The module and its connected components must be mounted to provide protection of at least IP20 in accordance with EN 60529: 1991 + A1: 2000.
- The outputs may be wired redundantly using the corresponding connector boards. For more information, see Chapters 3.6 and 4.5.

4.1.1 Wiring Outputs not in Use

Outputs that are not being used may stay open and need not be terminated. To prevent short-circuits and sparks in the field zone, never connect a wire to a connector board if it is open on the field side.

4.2 Mounting and Removing the Module

When replacing an existing module or mounting a new one, follow the instructions given in this chapter.

When removing the module, the connector board remains in the HIMax base plate. This saves additional wiring effort since all field terminals are connected via the connector board of the module.

4.2.1 Mounting a Connector Board

Tools and utilities

- Screwdriver, cross PH 1 or slotted 0.8 x 4.0 mm
- Matching connector board

To install the connector board

1. Insert the connector board into the guiding rail with the groove facing upwards (see following figure). Fit the groove into the guiding rail pin.
2. Place the connector board on the cable shield rail.
3. Secure the captive screws to the base plate. First screw in the lower screws than the upper ones.

To remove the connector board

1. Release the captive screws from the base plate.
2. Carefully lift the lower section of the connector board from the cable shield rail.
3. Remove the connector board from the guiding rail.




Figure 9: Example of how to Insert the Mono Connector Board




Figure 10: Example of how to Secure the Mono Connector Board with Captive Screws

i

These instructions also apply for redundant connector boards. The number of slots used varies in accordance with the connector board type. The number of captive screws depends on the connector board type.

4.2.2 Mounting and Removing the Module

This chapter describes how to mount and remove the HIMax module. A module can be mounted and removed while the HIMax system is operating.

NOTICE



Damage to bus and power sockets due to module jamming!

Failure to observe this can damage the controller.

Always take care when inserting the module in the base plate.

Tools and utilities


- Screwdriver, slotted 0.8 x 4.0 mm
- Screwdriver, slotted 1.2 x 8.0 mm

Installation

1. Open the cover plate on the fan rack:
 - Move the locks to the *open* position.
 - Lift the cover plate and insert into the fan rack
2. Insert the top of the module into the hook-in rail, see **1**.
3. Swivel the lower edge of the module towards the base plate and apply light pressure to snap it into place, see **2**.
4. Tighten the screws, see **3**.
5. Pull the cover plate out of the fan rack and close it.
6. Lock the cover plate.

Removal

1. Open the cover plate on the fan rack:
 - Move the locks to the *open* position.
 - Lift the cover plate and insert into the fan rack
2. Release the screw **3**.
3. Swivel the lower edge of the module away from the base plate. Lift and apply light pressure to remove the module from the hook-in rail, see **2** and **1**.
4. Pull the cover plate out of the fan rack and close it.
5. Lock the cover plate.



1 Inserting and Removing a Module

2 Swiveling a Module in and out

3 Securing and Releasing a Module

Figure 11: Mounting and Removing a Module

i

If the HIMax system is operating, do not open the cover plate of the fan rack for more than a few minutes (< 10 min) since this affects the forced cooling.

4.3 Line monitoring (SC/OC)

Line monitoring consists of monitoring for both short-circuits and open-circuits (SC/OC monitoring) and can be configured for each channel. The switching thresholds for line monitoring are predefined (see Table 8)

The following points must be taken into account for line monitoring (SC/OC):

- Line monitoring reliably detects an open-circuit (OC) if a load with current input of at least 10 mA is connected.
- If an actuator is redundantly connected to two modules, line monitoring reliably detects an open-circuit (OC) if a load with current input of at least 20 mA is connected.
- Line monitoring reliably detects a short-circuit (SC) when currents exceed 0.8 A.
- If an actuator is redundantly connected to two modules, line monitoring reliably detects a short-circuit (SC) when currents exceed 1.6 A.

Line monitoring (OC/SC) can be configured for each channel as follows:

- In the **I/O Submodule DO24_01** tab, adopt the setting *SC/OC Interval [μs]* (≥ 40 ms) for all channels
Default setting: 40 ms
- In the **I/O Submodule DO24_01**, activate *Show Open-Circuit* (indicated via the *Field* LED)
Default setting: Activated
- In the **I/O Submodule DO24_01: Channels**, activate *SC/OC active*,
Default setting: Activated
- In the **I/O Submodule DO24_01: Channels**, enter 0 μs...50 ms for *Max. Test Pulse Duration [μs]*, see recommended values Table 16.
Default setting: 0
The test pulse duration is at least 200 μs, even with the default setting or inputs < 1000. The parameter granularity is 1 ms (1000). The values are entered in μs.

4.3.1 Recommended Values for Line Monitoring

Test Impulse Duration	SC/OC Interval	Relationship
200 μs	40 ms	max. 0.5 %
1 ms	200 ms	max. 0.5 %
10 ms	2 s	max. 0.5 %
20 ms	4 s	max. 0.5 %
50 ms	10 s	max. 0.5 %

Table 16: Relationship between Test Impulse Duration and SC/OC Interval

For actuators, a pulse-duty factor of 0.5 % between the SC/OC interval and the test impulse duration has provided good results in practice. The value for the test impulse duration must always be lower than the value for the SC/OC interval.

If line monitoring is not functioning properly, a short-circuit or an open-circuit is indicated. Line monitoring does not affect the *Channel OK*, *Submodule OK* and *Module OK* statuses, see Chapter 4.4.

4.4 Configuring the Module in SILworX

The module is configured in the Hardware Editor of the SILworX programming tool.

Observe the following points when configuring the module:

- To diagnose the module and channels, both the statuses and the measured value can be evaluated within the user program. For more information on the statuses and parameters, refer to the tables starting with Chapter 4.4.1.
- If a redundancy group is created, its configuration is defined in the tabs. The tabs specific to the redundancy group differ from those of the individual modules, see the following tables.

To evaluate the statuses from within the user program, connect the module statuses to global variables. Perform this step in the Hardware Editor using the module's detail view.

The following tables present the statuses and parameters for the module in the same order given in the SILworX Hardware Editor.

TIP To convert hexadecimal values to bit strings a scientific calculator such as the Windows[®] calculator with the corresponding view can be used.

4.4.1 Tab: Module

The **Module** tab contains the statuses and parameters for the module:

Name		R/W	Description																		
Enter these statuses and parameters directly in the Hardware Editor.																					
Name		W	Module name																		
Spare Module		W	Activated: The module missing in the redundancy group is not considered as a fault. Deactivated: The module missing in the redundancy group is considered as a fault. Default setting: Deactivated It is only displayed in the redundancy group tab!																		
Noise Blanking		W	Noise blanking performed by processor module allowed (activated/deactivated). Default setting: Activated Status acknowledgments are suppressed until the safety time. The user program retains its last valid process value. Refer to the System Manual (HI 801 001 E) for more details about noise blanking.																		
Name	Data type	R/W	Description																		
The following statuses and parameters can be assigned global variables and used in the user program.																					
Module OK	BOOL	R	TRUE: Mono operation: No module faults. Redundant operation: At least one of the redundant modules is faultless (OR logic). FALSE: Module fault Channel fault (no external faults) The module is not plugged in. Observe the <i>Module Status</i> parameter!																		
Module Status	DWORD	R	Bit-coded module status <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>Coding</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0x00000001</td> <td>Module fault ¹⁾</td> </tr> <tr> <td>0x00000002</td> <td>Temperature threshold 1 exceeded</td> </tr> <tr> <td>0x00000004</td> <td>Temperature threshold 2 exceeded</td> </tr> <tr> <td>0x00000008</td> <td>Incorrect temperature value</td> </tr> <tr> <td>0x00000010</td> <td>Voltage L1+ is defective</td> </tr> <tr> <td>0x00000020</td> <td>Voltage L2+ is defective</td> </tr> <tr> <td>0x00000040</td> <td>Internal voltage is defective</td> </tr> <tr> <td>0x80000000</td> <td>No connection to the module ¹⁾</td> </tr> </tbody> </table> <p>¹⁾ These faults affect the <i>Module OK</i> status and need not be separately evaluated in the user program.</p>	Coding	Description	0x00000001	Module fault ¹⁾	0x00000002	Temperature threshold 1 exceeded	0x00000004	Temperature threshold 2 exceeded	0x00000008	Incorrect temperature value	0x00000010	Voltage L1+ is defective	0x00000020	Voltage L2+ is defective	0x00000040	Internal voltage is defective	0x80000000	No connection to the module ¹⁾
Coding	Description																				
0x00000001	Module fault ¹⁾																				
0x00000002	Temperature threshold 1 exceeded																				
0x00000004	Temperature threshold 2 exceeded																				
0x00000008	Incorrect temperature value																				
0x00000010	Voltage L1+ is defective																				
0x00000020	Voltage L2+ is defective																				
0x00000040	Internal voltage is defective																				
0x80000000	No connection to the module ¹⁾																				
Timestamp [µs]	DWORD	R	Microsecond fraction of the timestamp. Point in time at which the digital outputs were measured.																		
Timestamp [s]	DWORD	R	Second fraction of the timestamp. Point in time at which the digital outputs were measured.																		

Table 17: Module Tab in the Hardware Editor

4.4.2 Tab: I/O Submodule DO24_01

The **I/O Submodule DO24_01** tab contains the following statuses and parameters:

Name	R/W	Description	
Enter these statuses and parameters directly in the Hardware Editor.			
Name	W	Module name	
Output Noise Blanking	W	Allow output noise blanking performed by the output module (activated/deactivated). Default setting: Deactivated (recommended!) If a discrepancy exists between the channel's default and read-back values, the channel switch-off is suppressed.	
SC/OC Interval [μ s]	W	SC/OC interval of test impulse (≥ 40 ms) Default setting: 40 000 = 40 ms See Chapter 4.2.2	
Show Open-Circuit	W	Display via LED <i>Field</i> (activated/deactivated) Default setting: Activated	
Show Short-Circuit	W	Display via LED <i>Field</i> (activated/deactivated) Default setting: Activated	
Name	Data type	R/W	Description
The following statuses and parameters can be assigned global variables and used in the user program.			
Background Test Error	BOOL	R	TRUE: Background test is faulty FALSE: Background test is free of faults
Diagnostic Request	DINT	W	To request a diagnostic value, the appropriate ID must be sent to the module using the parameter <i>Diagnostic Request</i> (see Chapter 4.4.5 for coding details).
Diagnostic Response	DINT	R	As soon as <i>Diagnostic Response</i> returns the ID of <i>Diagnostic Request</i> (see Chapter 4.4.5 for coding details), <i>Diagnostic Status</i> contains the diagnostic value requested.
Diagnostic Status	DWORD	R	Requested diagnostic value in accordance with <i>Diagnostic Response</i> . The IDs of <i>Diagnostic Request</i> and <i>Diagnostic Response</i> can be evaluated in the user program. <i>Diagnostic Status</i> only contains the requested diagnostic value when both <i>Diagnostic Request</i> and <i>Diagnostic Response</i> have the same ID.
Restart on Error	BOOL	W	Using the parameter <i>Restart on Error</i> , each I/O module that has switched off permanently due to faults can be forced to re-adopt the RUN state. To do this, set the <i>Restart on Error</i> parameter FALSE to TRUE. The I/O module performs a complete self-test and only enters the RUN state if no faults are detected. Default setting: FALSE
Submodule OK	BOOL	R	TRUE: No submodule fault, no channel faults FALSE: Submodule fault. Channel fault (external faults included)
Submodule Status	DWORD	R	Bit-coded submodule status (For coding details, see Chapter 4.4.4)

Table 18: Tab: I/O Submodule DO24_01 in the Hardware Editor

4.4.3 Tab: I/O Submodule DO24_01: Channels

The **I/O Submodule DO24_01: Channels** tab contains the following parameters and statuses for each digital output.

Global variables can be assigned to the statuses and parameters with -> and used in the user program. The value without -> must be directly entered.

Name	Data type	R/W	Description
Channel no.	---	R	Channel number
Channel value [BOOL] ->	BOOL	W	Binary value in accordance with the switching level LOW (dig) and HIGH (dig). TRUE: Channel energized FALSE: Channel de-energized
-> Channel OK	BOOL	R	TRUE: Faultless channel The channel value is valid FALSE: Faulty channel The channel is de-energized
SC/OC active	BOOL	W	Short-circuit and open-circuit monitoring (activated/deactivated) Default setting: Activated
Max. test impulse duration [µs]	UDINT	W	Test impulse duration with line monitoring (OC/SC) Range of values: 0...50 000 µs Default setting: 0 µs
-> OC	BOOL	R	TRUE: Open-circuit FALSE: No open-circuit
-> SC	BOOL	R	TRUE: Short-circuit FALSE: No short-circuit
redund.	BOOL	W	Requirement: One redundant module must be configured. Activated: Activate the channel redundancy for this channel Deactivated: Deactivate the channel redundancy for this channel Default setting: Deactivated

Table 19: Tab: I/O Submodule DO24_01: Channels in the Hardware Editor

4.4.4 Submodule State [DWORD]

Coding of **Submodule Status**

Coding	Description
0x00000001	Fault in hardware unit (submodule).
0x00000002	Reset of an I/O bus
0x00000004	Fault detected while configuring the hardware
0x00000008	Fault detected while verifying the coefficients
0x00000010	First temperature threshold exceeded (warning temperature)
0x00000020	Second temperature threshold exceeded (limit temperature)
0x00000040	Overcurrent, module shutdown
0x00000080	Reset of CS monitoring (Chip Select monitoring)
0x00000100	Line monitoring hardware fault
0x00800000	Voltage monitoring of WD1: voltage error
0x01000000	Voltage monitoring of WD2: voltage error
0x02000000	Voltage monitoring of L1+ HIGH voltage defective
0x04000000	Voltage monitoring of L1+ LOW voltage defective
0x08000000	Voltage monitoring of L2+ HIGH voltage defective
0x10000000	Voltage monitoring of L2+ LOW voltage defective
0x20000000	Voltage monitoring of AGND voltage defective
0x40000000	Voltage monitoring of VMOS HIGH voltage defective
0x80000000	Voltage monitoring of VMOS LOW voltage defective

Table 20: Submodule State [DWORD]

4.4.5 Diagnostic Status [DWORD]

Coding of **Diagnostic Status**

ID	Description																		
0	Diagnostic values are indicated consecutively.																		
100	Bit-coded temperature status 0 = normal Bit0 = 1 : Temperature threshold 1 has been exceeded Bit1 = 1 : Temperature threshold 2 has been exceeded Bit2 = 1 : Fault in temperature measurement																		
101	Measured temperature (10 000 Digit/ °C)																		
200	Bit-coded voltage status 0 = normal Bit0 = 1 : L1+ (24 V) is faulty Bit1 = 1 : L2+ (24 V) is faulty																		
201	Not used!																		
202																			
203																			
300	Comparator 24 V low voltage (BOOL)																		
1001...1024	<table border="1"> <thead> <tr> <th colspan="2">Status of channels 1...24</th> </tr> <tr> <th>Coding</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0x0001</td> <td>Fault in hardware unit (submodule).</td> </tr> <tr> <td>0x0002</td> <td>Reset of an I/O bus</td> </tr> <tr> <td>0x0008</td> <td>Read-back value 0 on the output with reference value 1, due to hardware fault</td> </tr> <tr> <td>0x0010</td> <td>Short-circuit detected</td> </tr> <tr> <td>0x0020</td> <td>Open-circuit detected</td> </tr> <tr> <td>0x0040</td> <td>Fault Read back value = 1 at set point = 0</td> </tr> <tr> <td>0x0080</td> <td>Read back value = 0 at set point = 1 due to a field fault</td> </tr> </tbody> </table>	Status of channels 1...24		Coding	Description	0x0001	Fault in hardware unit (submodule).	0x0002	Reset of an I/O bus	0x0008	Read-back value 0 on the output with reference value 1, due to hardware fault	0x0010	Short-circuit detected	0x0020	Open-circuit detected	0x0040	Fault Read back value = 1 at set point = 0	0x0080	Read back value = 0 at set point = 1 due to a field fault
Status of channels 1...24																			
Coding	Description																		
0x0001	Fault in hardware unit (submodule).																		
0x0002	Reset of an I/O bus																		
0x0008	Read-back value 0 on the output with reference value 1, due to hardware fault																		
0x0010	Short-circuit detected																		
0x0020	Open-circuit detected																		
0x0040	Fault Read back value = 1 at set point = 0																		
0x0080	Read back value = 0 at set point = 1 due to a field fault																		

Table 21: Diagnostic Status [DWORD]

4.5 Connection Variants


This chapter describes the correct wiring of the module in safety-related applications. The connection variants specified here are permitted.

The outputs are wired via connector boards. Special connector boards are available for redundantly wiring the modules, see Chapter 3.6.

The following points must be taken into account when connecting the loads to the outputs:

- A protective circuit (free-wheeling diode) is required when connecting inductive loads.
- Unshielded, twisted pair cables may be connected.
- The ground wires of the actuators in the field may not be interconnected.

4.5.1 Wiring Actuators



1 Actuators

Figure 12: Wiring of the Module with Actuators


NOTICE



The module outputs must be connected with two poles.
 The ground wires of the actuators in the field may not be interconnected.
 The use of common lines can cause coupling loops. This may result in interferences (e.g., of line monitoring) up to the module's shutdown or line monitoring failure.

4.5.2 Redundant Wiring of Actuators via Two Modules

When actuators are redundantly wired, the general requirements for line monitoring must be observed, see Chapter 4.3.



1 Actuators

Figure 13: Redundant Wiring of Actuators


NOTICE



The wiring described above is only allowed if both channels have identical channel numbers.

4.5.3 Wiring Inductive Loads

When connecting inductive loads, a protective circuit (such as a suitable free-wheeling diode) must be connected in parallel to the load.




1 Inductive Load

Figure 14: Wiring Inductive Loads

4.5.4 Wiring Actuators via Field Termination Assembly

Actuators are connected via the X-FTA 002 01 as described in Figure 15. For further information, refer to the X-FTA 002 01 Manual (HI 801 117 E).



1 Actuators

2 System Cable with Cable Plug

Figure 15: Wiring Actuators via Field Termination Assembly

5 Operation

The module runs within a HIMax base plate and does not require any specific monitoring.

5.1 Handling

Direct handling of the module is not foreseen.

The module is operated from within the PADT, e.g., for forcing the outputs. For more details, refer to the SILworX documentation.

5.2 Diagnosis

LEDs on the front side of the module indicate the module state, see Chapter 3.4.2.

The module diagnostic history can also be read using the programming tool SILworX. Chapter 4.4.4 and Chapter 4.4.5 describe the most important module-specific diagnostic messages.

i

If a module is plugged in to a base plate, it generates diagnostic messages during its initialization phase indicating faults such as incorrect voltage values.

These messages only indicate a module fault if they occur after the system starts operation.

6 Maintenance

Defective modules must be replaced with a faultless module of the same type or with an approved replacement model.

Only the manufacturer is authorized to repair the module.

When replacing modules, observe the instructions specified in the System Manual (HI 801 001 E) and Safety Manual (HI 801 003 E).

6.1 Maintenance Measures

6.1.1 Loading the Operating System

HIMA is continuously improving the operating system of the module. HIMA recommends to use system downtimes to load the current version of the operating system into the module.

For detailed instructions on how to load the operating system, see the system manual and the online help. The module must be in STOP to be able to load an operating system.

i

The current version of the module in use is displayed in the SILworX Control Panel! The type label specifies the version when the module is delivered, see Chapter 3.3.

6.1.2 Proof Test

HIMax modules must be subjected to a proof test in intervals of 10 years. For more information, refer to the Safety Manual HI 801 003 E.

7 Decommissioning

To decommission the module, remove it from the base plate. For more information, see *Mounting and Removing the Module*.

8 Transport

To avoid mechanical damage, HIMax components must be transported in packaging.

Always store HIMax components in their original product packaging. This packaging also provides protection against electrostatic discharge. Note that the product packaging alone is not suitable for transport.

9 Disposal

Industrial customers are responsible for correctly disposing of decommissioned HIMax hardware. Upon request, a disposal agreement can be arranged with HIMA.

All materials must be disposed of in an ecologically sound manner.



Appendix

Glossary

Term	Description
ARP	Address Resolution Protocol: Network protocol for assigning the network addresses to hardware addresses
AI	Analog Input
Connector Board	Connector board for the HIMax module
COM	Communication module
CRC	Cyclic Redundancy Check
DI	Digital Input
DO	Digital Output
EMC	Electromagnetic Compatibility
EN	European Norm
ESD	ElectroStatic Discharge
FB	Fieldbus
FBD	Function Block Diagram
FTT	Fault Tolerance Time
ICMP	Internet Control Message Protocol: Network protocol for status or error messages
IEC	International Electrotechnical Commission
MAC address	Hardware address of one network connection (Media Access Control)
PADT	Programming And Debugging Tool (in accordance with IEC 61131-3), PC with SILworX
PE	Protective Earth
PELV	Protective Extra Low Voltage
PES	Programmable Electronic System
PFD	Probability of Failure on Demand, probability of failure on demand of a safety function
PFH	Probability of Failure per Hour, probability of a dangerous failure per hour
R	Read
r_p	Peak value of a total AC component
Rack ID	Base plate identification (number)
Interference-free	Supposing that two input circuits are connected to the same source (e.g., a transmitter). An input circuit is termed "non-reactive" if it does not distort the signals of the other input circuit.
R/W	Read/Write
SB	System Bus (Module)
SELV	Safety Extra Low Voltage
SFF	Safe Failure Fraction, portion of safely manageable faults
SIL	Safety Integrity Level (in accordance with IEC 61508)
SILworX	Programming tool for HIMax
SNTP	Simple Network Time Protocol (RFC 1769)
SRS	System.Rack.Slot addressing of a module
SW	Software
TMO	TiMeOut
W	Write
Watchdog (WD)	Time monitoring for modules or programs. If the watchdog time is exceeded, the module or program enters the ERROR STOP state.
WDT	WatchDog Time

Index of Figures

Figure 1: Sample Type Label	11
Figure 2: Block Diagram	13
Figure 3: Indicators	14
Figure 4: Views	17
Figure 5: Coding Example	20
Figure 6: Connector Boards with Screw Terminals	21
Figure 7: Connector Boards with Cable Plug	24
Figure 8: X-CA 010 01 n	26
Figure 9: Example of how to Insert the Mono Connector Board	29
Figure 10: Example of how to Secure the Mono Connector Board with Captive Screws	30
Figure 11: Mounting and Removing a Module	32
Figure 12: Wiring of the Module with Actuators	40
Figure 13: Redundant Wiring of Actuators	41
Figure 14: Wiring Inductive Loads	42
Figure 15: Wiring Actuators via Field Termination Assembly	42

Index of Tables

Table 1:	Additional Valid Manuals	5
Table 2:	Environmental Requirements	8
Table 3:	Blinking Frequencies of LEDs	15
Table 4:	Module Status Indicators	15
Table 5:	System Bus Indicators	16
Table 6:	I/O Indicators	16
Table 7:	Product Data	17
Table 8:	Specifications for the Digital Outputs	18
Table 9:	Available Connector Boards	19
Table 10:	Position of Coding Wedges	20
Table 11:	Terminal Assignment for Connector Boards with Screw Terminals	22
Table 12:	Cable Plug Properties	23
Table 13:	Pin Assignment for the System Cable Plug	25
Table 14:	Cable Data	26
Table 15:	Available System Cables	26
Table 16:	Relationship between Test Impulse Duration and SC/OC Interval	33
Table 17:	Module Tab in the Hardware Editor	35
Table 18:	Tab: I/O Submodule DO24_01 in the Hardware Editor	36
Table 19:	Tab: I/O Submodule DO24_01: Channels in the Hardware Editor	37
Table 20:	Submodule State [DWORD]	38
Table 21:	Diagnostic Status [DWORD]	39

Index

block diagram	13	system bus indicators	16
connection variants	40	digital outputs.....	18
connector boards	19	line monitoring	33
diagnosis	43	module status indicators	15
I/O indicators	16	specifications	17

HI 801 019 E

© 2012 HIMA Paul Hildebrandt GmbH + Co KG
HIMax and SILworX are registered trademark of:
HIMA Paul Hildebrandt GmbH + Co KG

Albert-Bassermann-Str. 28
68782 Brühl, Germany
Phone +49 6202 709-0
Fax +49 6202 709-107
HIMax-info@hima.com
www.hima.com



SAFETY
NONSTOP